


User-Guide PolyStudioX50 Game Changer meeting room


1. Turn on TV and select “Device mode”.



2. Plug USB and HDMI cable from table to laptop.



3. Check whether the device has been set into Polycom.



User-Guide Samsung TV Touch screen

1. Turn on TV. (The arrow shows the power button)



2. Use Touch pen to draw or write and hand to erase.



3. Click arrow to use different tools.

