


User-Guide Game Changer meeting room


1. Turn on TV and select „Device Mode“



2. Plug USB and HDMI cable from table to laptop



3. You can use Screen and Camera



User guide for Polycom remote control



Save Camera Presets

The two number buttons on the Polycom Studio remote control serve as camera presets.

To save a camera preset:

1. Turn off group framing and speaker tracking mode.
2. Adjust the camera.
3. Long press the 1 or 2 button on the remote control. The middle LED lights stay

If you have trouble connecting, please call 777 (+4969271472777)

HME Technical Helpdesk